

EWF Series Standard Stroke Balancers



EWF-9

The EWF Series features fully enclosed housing, fall-arrest device (auto-brake), and manual drum locks. If a spring breaks, the brake automatically locks to prevent tool damage. The manual drum lock keeps the drum from rotating to allow easy change out and maintenance of tools. Springs are enclosed in a replaceable cartridge for safe and easy repair.

Note: EWF Series Balancers are also available in an **unpainted version**. To order, add "-NP" at the end of the standard "EWF" part number.

Note: EWF Series Balancers are also available without the adjustable stopper. To order, add "-NS" at the end of the standard "EWF" part number.

Max. Capacity lb (kg)	Cable Travel ft (m)	Part No.	Cable Dia in. (mm)	Wt lb (kg)
9.9 to 19.8 (4.5 to 9.0)	4.27 (1.3)	EWF-9	0.16 (4.0)	7.5 (3.4)
19.8 to 33.1 (9.5 to 15.0)	4.93 (1.5)	EWF-15	0.16 (4.0)	8.4 (3.8)
33.1 to 48.5 (15 to 22)	4.93 (1.5)	EWF-22	0.19 (4.8)	16.1 (7.3)
48.5 to 66.1 (22 to 30)	4.93 (1.5)	EWF-30	0.19 (4.8)	17.0 (7.7)
66.1 to 88.2 (30 to 40)	4.93 (1.5)	EWF-40	0.19 (4.8)	21.4 (9.7)
88.2 to 110.2 (40 to 50)	4.93 (1.5)	EWF-50	0.19 (4.8)	22.2 (10.1)
110.2 to 132.3 (50 to 60)	4.93 (1.5)	EWF-60	0.19 (4.8)	24.5 (11.1)
132.3 to 154.3 (60 to 70)	4.93 (1.5)	EWF-70	0.19 (4.8)	25.1 (11.4)
154.3 to 198.4 (70 to 90)	6.56 (2.0)	EWF-90	0.19 (4.8)	48.5 (22.0)
198.4 to 231.5 (90 to 105)	6.56 (2.0)	EWF-105	0.19 (4.8)	53.0 (24.0)
231.5 to 264.5 (105 to 120)	6.56 (2.0)	EWF-120	0.19 (4.8)	61.7 (28.0)

For dimensional drawings, see Pg. 22



EWF-30



EWF-40



EWF-90